A new vibrator is a bit like a new partner...



each other first.

First Things First




To turn it on, click on the button

Light blinking

=Low battery



Click again to navigate between the 4 speeds and 2 pulsation modes




Charging



To turn off, press and hold the button. To turn on/off the travel lock, press again for 4s



Fully charged



- Help build arousal and increase vulva sensations

Erogenous zones

• Dense areas of nerve receptors ultra-sensitive to touch

DISCOVER YOURSELF

Remember that your vibrator is a device, but your body isn't! What brings pleasure varies between vulva owners, and from one day to the next. Keep on exploring yourself, be curious about your sensations and renew the experience every time.

Just like you would for good partner sex!

Pleasure Tips



Recreate oral sex by stroking your French Lover vibrator back and forth across the clitoris and labia, just like a real tongue.



Enjoy breast stimulation by tickling your nipples with The French Lover's tongue. Start off light, then slowly build up arousal.



Add lubricant to the tip of the tongue for a more realistic feel, then play with speeds and pulsations for a different experience.



Move away from the vulva and discover other pleasure spots. Your whole body can become erogenous.

Vibrator Hygiene



Your French Lover likes it wet. To keep it clean and happy, wash it with water and soap, then pat it dry. We recommend doing this before and after use.



Scan for more tips

Wanna Duet?

Join us in breaking taboos.
For a chance to be featured,
show off your new hot lover
or share where you keep your
new vibe by tagging us:

@SmileMakersCollection Your daily dose of sex positivity





